

# DW7QSXSA-1



|                   |               |
|-------------------|---------------|
| Product Family    | Dishwashers   |
| Commercial width  | 60 cm         |
| Commercial height | 85 cm         |
| Installation      | Free-standing |
| N° baskets        | 3, FlexiDuo   |
| EAN code          | 8017709273118 |



## Programs



|                      |                       |                    |     |
|----------------------|-----------------------|--------------------|-----|
| N. of programmes     | 10+1                  | Intense            | Yes |
| Washing temperatures | 38, 45, 50, 65, 70 °C | Self clean         | Yes |
| Soak                 | Yes                   | Hygiene 99,9%      | Yes |
| Rapid 27'            |                       | 1/2 load           |     |
| Express 27'          | Yes                   | Delicate           | Yes |
| Glass                | Yes                   | ECO Quick          |     |
| ECO                  | Yes                   | Delicate and Quick |     |
| Green express        | Yes                   | Normal Quick       |     |
| Normal               |                       | Strong and fast    |     |
| Mix                  | Yes                   | Express 60'        | Yes |
| Ultraclean           |                       |                    |     |

## Options



|                           |                |                         |     |
|---------------------------|----------------|-------------------------|-----|
| Dry Assist+ option        | Yes            | Options for tabs        |     |
| Delay timer option        | Up to 24 hours | FlexiTabs               |     |
| Extra dry option          |                | Quick Time option       |     |
| 1/2 load FlexiZone option | Yes            | Special programs option | Yes |

## Baskets



|  |                                      |  |  |
|--|--------------------------------------|--|--|
| <b>Basket colour</b>                         | Grey                                 | <b>Largest loadable dish in upper basket</b> | 19,0 cm  |
| <b>Basket components colour</b>              | Grey                                 | <b>Lower Basket</b>                          | With 2 foldable racks                              |
| <b>Handle</b>                                | In plastic on upper and lower basket | <b>Lower basket with anti-drip inserts</b>   | Yes  |
| <b>Upper Basket</b>                          | With 1 foldable rack                 | <b>Largest loadable dish in lower basket</b> | 30,0 cm  |
| <b>Height adjustment of the upper basket</b> | On three levels (5 cm)               | <b>Colour Inner Components</b>               | Blue anti drop inserts, Blue handles, Blue Orbital |


## Technical Features



|                               |   |  |  |
|-------------------------------|---|--|--|
| <b>Width (mm)</b>             | 598 mm  | <b>Water softener</b>                          | With electronic setting  |
| <b>Depth (mm)</b>             | 600 mm  | <b>Flood protection system</b>                 | Total Acquastop  |
| <b>Display type</b>           | LED display (3 digit)   | <b>Water supply</b>                            | Single; cold/hot water max. 60°C - energysave with hot water up to 35% |
| <b>Product Height (mm)</b>    | 848 mm  | <b>Max water hardness</b>                      | 100°FH;58°dH   |
| <b>Controls</b>               | Electronic  | <b>Drying system</b>                           | Natural condenser drying   |
| <b>Display</b>                | Delayed start, Programme time indicator, Time to end indication | <b>Tube material</b>                           | Stainless steel  |
| <b>Programme graphics</b>     | Symbols   | <b>Filter</b>                                  | Stainless steel  |
| <b>On/off indicator</b>       | Yes   | <b>Concealed heating element</b>               | Yes  |
| <b>Salt light indicator</b>   | Light   | <b>Hinges</b>                                  | Self balancing with fixed hinges                                       |
| <b>Rinse aid indicator</b>    | Light   | <b>Adjustable feet</b>                         | Just for levelling   |
| <b>Progress indicator</b>     | Yes   | <b>Back cover</b>                              | Yes, with covered counterweight  |
| <b>End of cycle indicator</b> | On display, with acoustic signal                                | <b>Depth of dishwasher with open door (mm)</b> | 1168 mm  |
| <b>Washing system</b>         | Orbital   | <b>Removable top</b>                           | Yes, with optional KIT   |
| <b>Third spray arm</b>        | Single  |  |  |

## Electrical Connection

|                        |           |                                  |                |
|------------------------|-----------|----------------------------------|----------------|
| <b>Connected power</b> | 1800 W    | <b>Type of connection</b>        | Single-phase   |
| <b>Current</b>         | 10 A      | <b>Power supply cable length</b> | 140 cm         |
| <b>Voltage</b>         | 220-240 V | <b>Plug</b>                      | (M) Sud Africa |
| <b>Frequency (Hz)</b>  | 50 Hz     |                                  |                |



---

## Compatible Accessories

---

### KITGH



Kit glass holder. It has to be fitted on the first basket but only if there are foldable racks

### KITPLV2

























Kit extension for dishwasher and washing machine: lenght mt. 2

### KITINC



## Symbols glossary

|   |  |
|---|--|
|  To improve the drying of dishes without leaving stains.  |  A++: Energy efficiency class A++ helps to save up to 20% energy compared to class A. Maximum performance with minimum consumption is guaranteed.   |
|  Delay Timer: Option to postpone the start of the desired programme by up to 24 hours in order to programme the dishwasher to run at the desired time.  |  Fingerprint proof stainless steel: Fingerprint proof stainless steel keeps stainless steel looking as good as new.   |
|  FlexiDuo: The FlexiDuo 3rd cutlery basket allows you to arrange cutlery or small cups, ladles, or bulky utensils however you like: it consists of two separate and moveable modules.         |  FlexiZone: The ½ load flexizone allows you to wash a reduced load saving energy, water and time and there are no restrictions on where the items are placed.   |
|  47 dB Noise Level: Excellent insulation and special devices keep noise to a minimum.   |  Orbital wash system distributes water evenly throughout the 60cm dishwasher cavity, directing water with precision to ensure an excellent wash.  |
|  50° Delicate: Delicate washing program is designed for delicate dishes which are not heavily soiled.  |  ECO 50° Eco: Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.   |
|  65° Mix: The Mix programme is suitable for mixed crockery and everyday pots and pans, without any particular incrustation.   |  Soak programme: The soak programme provides a rinse to prevent dirt from drying.   |
|  Express 27': The Express 27' programme is a quick wash cycle, at low temperatures, for lightly soiled dishes.  |  Ultraclean: The Ultraclean option performs a final rinse at a high temperature of 70°C eliminating virtually all bacteria.   |
|  14 place settings: Number of place settings.   |  Total Acquastop: In addition to the partial Acquastop protection present in all Smeg dishwashers, some models have an electronic device fitted to the water intake hose, which monitors water levels in the machine, detects leaks in the hose and switches off the water supply immediately when necessary. |
|  9 lit System WaterSave ensures the best washing results with minimal water consumption depending on the model of dishwasher.   |  GREEN EXPRESS Washing programme with low water and energy consumption.   |
|  Dishwasher cleaning cycle. The cycle should be started with the machine empty, without dishes. It is recommended to run the program every 2-3 months, using special dishwasher detergents. |  Allows you to enable additional programs when selected together with any wash cycle.   |
|  The Dry Assist + option, in addition to saving energy, ensures perfect drying of the dishes by opening the door automatically at the end of the washing cycle.                             |  HYGIENE 99.9% High-temperature washing programme. The 75° rinse guarantees the removal of 99.9% of germs and bacteria.   |