

DWAI6214X2



Product Family Dishwashers
Commercial width 60 cm
Commercial height 82 cm

Installation Partially-integrated built-in

Kitchen panel Not supplied

N° baskets

EAN code 8017709278687



Programs / Functions







N. of programmes5UltracleanYesWashing temperatures45, 50, 65, 70 °CIntensive 65°YesSoakYesNormal ECOYesECOYes

Options





Delay timer option 3-6-9 hours Options for tabs Yes

Baskets



Basket colour Grey Lower Basket With 2 foldable racks

Basket components Grey Lower basket with anti- Yes

colour drip inserts

Handle In plastic on upper and Largest loadable dish in 30,0 cm

lower basket lower basket

Upper BasketWith central fixed racksColour InnerGrey handles, Grey pastic....Componentsplate for regulation second

Height adjustment of On three levels basket on three levels,

the upper basket

Green Orbital

Largest loadable dish in 25,0 cm

upper basket Cutlery basket 13 place settings sliding



Technical Features







Width (mm) 598 mm

Depth (mm) 570 mm

Product Height (mm) 818 mm

Controls Electronic

Programme graphics Symbols

On/off indicator Yes

Rinse aid indicator Light

End of cycle indicator Led on display, with acoustic signal

Washing system Orbital
Third spray arm Single

Flood protection system Total Acquastop

Water supply Single; cold/hot water max.

60°C - energysave with hot

water up to 35%

Max water hardness 100°fH;58°dH

Drying system Natural condenser drying Steam protection In plastic

Child safety system (door lock)

Tub materialStainless steelFilterStainless steel

Concealed heating element

Hinges

Min. and max plinth

height

Adjustable feet Additional gaskets

plate
Back cover
Yes
Depth of dishwasher 1146

with open door (mm)

Top cover

In plastic

Yes

Yes

hinges

100 - 215 mm

Self balancing with fixed

7cm, from 820 to 890 mm

Yes, with stainless steel

Electrical Connection

Plug (I) Australia
Connected power 1800 W
Current 10 A
Voltage 220-240 V

Frequency (Hz)
Type of connection
Power supply cable
length

50 Hz Single-phase 140 cm



Not included accessories

KITPL60FABB



Toekick Kit in White colour with adjustable height. Can be fitted over all the fully integrated and underbench models with Fixed Fulcrum. Can be installed also on the models with variable fulcrum or flexifit hinges.

KITPL60FABN



Toekick Kit in Black colour with adjustable height. Can be fitted over all the fully integrated and underbench models with Fixed Fulcrum. Can be installed also on the models with variable fulcrum or flexifit hinges.

KITGH



Kit glass holder. It has to be fitted on the first basket but only if there are foldable racks

KITPL60FABX

Toekick Kit in Stainless Steel with adjustable height. Can be fitted over all the fully integrated and underbench models with Fixed Fulcrum. Can be installed also on the models with variable fulcrum or flexifit hinges.

KITPLV2



Kit extension for dishwasher and washing machine: lenght mt. 2



Symbols glossary (TT)



Anti-drip: Some models of dishwashers are equipped with special polymer nozzles anti-drip, that improve the process of drying.



Child lock: some models are fitted with a device to lock the programme/cycle so it cannot be accidentally changed.



COMM_HEIGHT_82_72dpi



Delay Timer: The delay timer can postpone the start of the program by up to 24 hours.



Flexitabs: Flexitabs adjusts the wash cycle to give the best possible results regardless of the type of detergent used.



Noise Level: Excellent insulation and special devices keep noise to a minimum.



Orbital wash system distributes water evenly throughout the 60cm dishwasher cavity, directing water with precision to ensure an excellent wash.



Eco: Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.



Soak programme: The soak programme provides a rinse to prevent dirt from drying.



The symbols show the number of plate settings of the dishwasher.



Total Acquastop: In addition to the partial Acquastop protection present in all Smeg dishwashers, some models have an electronic device fitted to the water intake hose, which monitors water levels in the machine, detects leaks in the hose and switches off the water supply immediately when necessary.



System WaterSave ensures the best washing results with minimal water consumption depending on the model of dishwasher.