DWAU6315X4



Product Family	Dishwashers
Commercial width	60 cm
Commercial height	82 cm
Installation	Under counter built-in
N° baskets	3, Flexi
Motor	Inverter 2.0
EAN code	8017709366520

Programs

N. of programmes	8	**ECO**	Yes
Washing temperatures	45, 50, 65, 70, 75 °C	**Auto sensor 45-65**	Yes
Soak	Yes	**Mix**	Yes
Crystal	Yes	**Self clean**	Yes
Express 50°	Yes	**Intense 60°**	Yes

Options

Delay timer option	Up to 24 hours	**Crystal option**	Yes
Extreme option	Yes	**Sterilise option**	Yes

Baskets

Basket colour	Grey	**Largest loadable dish in upper basket**	19,0 cm
Basket components colour	Grey	**Lower Basket**	With 4 foldable racks
Handle	In plastic with stainless steel insert on upper and lower basket	**Largest loadable dish in lower basket**	31.0 cm
Upper Basket	With 2 foldable racks	**Colour Inner Components**	Blue
Height adjustment of the upper basket	On two levels (4 cm)		


Technical Features



Width (mm)	597 mm
Depth (mm)	550 mm
Display type	LED display
Product Height (mm)	818 mm
Controls	Electronic
Display	Delayed start, Programme time indicator, Time to end indication
Programme graphics	Symbols
Rinse aid indicator	Light
Progress indicator	Yes
End of cycle indicator	On display, with acoustic signal
Auto switch-off	Yes
Washing system	Standard
Third spray arm	Single
Turbidity sensor Aquatest	Yes
Flood protection system	Total Acquastop
Water supply	Single; cold/hot water max. 60°C - energysave with hot water up to 35%
Max water hardness	90°fH; 50°dH
Drying system	Natural condenser drying, with Dry Assist + automatic door opening system at the end of the cycle
Steam protection	In plastic
Tub material	Stainless steel
Filter	Stainless steel
Concealed heating element	Yes
Hinges	Self balancing with fixed hinges
Min. and max plinth height	40 - 220 mm
Adjustable feet	8 cm, da 818 a 898 mm
Airborne acoustical noise emissions dBA	45 dBA
Back cover	
Depth of dishwasher with open door (mm)	1180 mm
Back feet adjustable from front	
Top cover	

Electrical Connection

Connected power	1800 W
Current	10 A
Voltage	220-240 V
Frequency (Hz)	50 Hz
Type of connection	Single-phase
Power supply cable length	140 cm
Plug	(I) Australia


596
570
min.570
820-880
818-878
685
710
600
150
50
max.130
1180
* 820
**900
* 40
**220

Symbols glossary



Aquatest measures the clarity of the water during an auto program, and automatically ensures the minimum consumption of water and energy.



Delay Timer: The delay timer can postpone the start of the program by up to 24 hours.



Noise Level: Excellent insulation and special devices keep noise to a minimum.



Auto 45°- 65°: The auto programme regulates the length of a cycle depending on the need for a pre-wash and the number of rinses required.



Eco: Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.



Soak programme: The soak programme provides a rinse to prevent dirt from drying.



Total Acquastop: In addition to the partial Acquastop protection present in all Smeg dishwashers, some models have an electronic device fitted to the water intake hose, which monitors water levels in the machine, detects leaks in the hose and switches off the water supply immediately when necessary.



...



Programme suitable for washing and drying heavily soiled items with encrusted residues.



Option which provides better cleaning results by keeping the temperature between 65 and 70°C for at least 10 minutes during the last rinsing phase.



COMM_HEIGHT_82_72dpi



This option provides special care for a delicate load. It prevents rapid changes in the wash temperature of the selected programme and reduces it to 4



Noise Level: Excellent insulation and special devices keep noise to a minimum.



Crystals: The Crystals programme is dedicated to delicate dishes such as glasses and china.



Normal programme: The normal programme is suitable for normal degrees of dirt for everyday use.



The symbols show the number of plate settings of the dishwasher.



System WaterSave ensures the best washing results with minimal water consumption depending on the model of dishwasher.



Dishwasher cleaning cycle. The cycle should be started with the machine empty, without dishes. It is recommended to run the program every 2-3 months, using special dishwasher detergents.



Option which improves the washing results of the selected programme. It increases the wash temperature and duration.



The work aimed at continuous improvement has allowed the creation of the second generation of the Inverter motor 2.0, characterised by greater efficiency and durability over time, which allows very high performance and a lower energy consumption and noise level.