

DWI9QDLSA-1





Product Family Dishwashers Commercial width 60 cm Commercial height 82 cm

Installation Fully-integrated built-in

Kitchen panel Not supplied N° baskets 3, FlexiDuo EAN code 8017709274061



Programs























N. of programmes 10 + 1Washing temperatures 38, 45, 50, 65, 70 °C Soak Express 27' Yes Crystal Yes Full express - 60 Yes minutes

ECO Yes Auto sensor 45-65 Yes

Yes Quiet (-2 dB) Yes Intense Yes Self clean Yes Hygiene 99,9% Yes

Options









Dry Assist+ option

Delay timer option

1/2 load FlexiZone

option

Yes

Up to 24 hours

Yes

Special programs option Yes

Baskets





Basket colour Grey

Basket components colour

Grey

Largest loadable dish in 19,0 cm

upper basket

Lower Basket With 4 foldable racks



Handle

In plastic with stainless

lower basket

Upper Basket Height adjustment of the upper basket

Upper basket with EasyGlide System

steel insert on upper and

With 3 foldable racks

On three levels (5 cm)

Yes

Lower basket with anti- Yes

drip inserts

Largest loadable dish in 30,0 cm

lower basket

Colour Inner Components Blue

Technical Features













Width (mm) Depth (mm)

Display type

Product Height (mm) Watersave system

Controls

Display

598 mm 545 mm

LED display (3 digit)

Yes

Delayed start, Programme

time indicator

Programme graphics On/off indicator Salt light indicator Rinse aid indicator End of cycle indicator

Washing system Third spray arm

Water softener **Turbidity** sensor

Aquatest

818 mm

Electronic

Symbols Yes Light

Light ActiveLight Planetarium

Sinale

With electronic setting

Yes

Flood protection system Total Acquastop

Water supply

Drying system

Single; cold/hot water max.

60°C - energysave with hot water up to 35%

100°fH;58°dH Max water hardness

> Natural condenser drying, with EnerSave automatic door opening system at the

> > end of the cycle

Steam protection In plastic Tub material Stainless steel Filter Stainless steel

Concealed heating

element Hinges

Min. and max. frontal panel weight

Min. and max plinth

height

Adjustable feet Back cover

Depth of dishwasher with open door (mm)

Back feet adjustable

from front

Top cover

Self balancing, Sliding,

FLEXIFIT

Yes

2,5 - 11 kg

50 - 215 mm

7cm, from 820 to 890 mm

Yes 1146

Yes

In plastic

Electrical Connection

Plug

Connected power

Current Voltage

(M) Sud Africa 1800 W

10 A 220-240 V Frequency (Hz)

Type of connection Power supply cable


length

50 Hz

Single-phase

140 cm







Compatible Accessories



KIT82CN



KIT82CX



KIT82SPRAN



KIT82SPRMW



KIT82SPRX



KITFLEXI Kit for 60cm dishwashers with FlexiFit hinges for door panel weight >11 kg


(max 15 kg 82 cm and 13,5 kg 86 cm)

KITGH

Kit glass holder. It has to be fitted on the first basket but only if there are foldable racks



KITPL60B






KITPL60N

Toekick Kit in Black colour with adjustable height and deepness. Can be installed over all the fully integrated and underbench models with variable fulcrum or flexifit hinges.



KITPL60X







Kit extension for dishwasher and washing machine: lenght mt. 2





Symbols glossary



Activelight is an led light which projects a red spot onto the floor beneath the dishwasher when the appliance is in use.



The Aquatest sensor is an electronic sensor that measures the degree of water transparency at the end of the initial soaking phase. ased on the values measured, the sensor sets the most suitable programme, thus obtaining the best washing results with the minimum amount of water.





To improve the drying of dishes without leaving stains.



82 cm high



Delay Timer: Option to postpone the start of the desired programme by up to 24 hours in order to programme the dishwasher to run at the desired time



EasyGlide: Convenient EasyGlide system for easy unloading of the appliance that allows reaching maximum flexibility of load of the machine.



FlexiDuo: The FlexiDuo 3rd cutlery basket allows you to arrange cutlery or small cups, ladles, or bulky utensils however you like: it consists of two separate and moveable modules.



The FlexiFit hinges allow the kitchen panel to slide over the dishwasher door, allowing a minimum kitchen plinth height of 5 cm.



FlexiZone: The ½ load flexizone allows you to wash a reduced load saving energy, water and time and there are no restrictions on where the items are placed.



Noise Level: Excellent insulation and special devices keep noise to a minimum.



The Planetarium washing system, with high rotations per minute, guarantees complete coverage of the tank, thanks to the simultaneous rotation of base and sprayers, and excellent washing results.



Auto 45°- 65°: The auto programme regulates the length of a cycle depending on the need for a pre-wash and the number of rinses required.



Crystals: The Crystals programme is dedicated to delicate dishes such as glasses and china.



Eco: Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.



Mix: The Mix programme is suitable for mixed crockery and everyday pots and pans, without any particular incrustation.



Soak programme: The soak programme provides a rinse to prevent dirt from drying.



Express 27': The Express 27' programme is a quick wash cycle, at low temperatures, for lightly soiled dishes.



Ultraclean: The Ultraclean option performs a final rinse at a high temperature of 70°c eliminating virtually all bacteria.



14 place settings: Number of place settings.



Total Acquastop: In addition to the partial Acquastop protection present in all Smeg dishwashers, some models have an electronic device fitted to the water intake hose, which monitors water levels in the machine, detects leaks in the hose and switches off the water supply immediately when necessary.



System WaterSave ensures the best washing results with minimal water consumption depending on the model of dishwasher.





Quick wash cycle for normally soiled mixed loads such as dishes and pans, even with dried-on residues. Dishes are washed and dried in 60 minutes.



Dishwasher cleaning cycle. The cycle should be started with the machine empty, without dishes. It is recommended to run the program every 2-3 months, using special dishwasher detergents.



SILENT: Wash cycle suitable for normally soiled dishes, even with dried-on residues. Ensures maximum noise reduction and is therefore ideal if you wish to run it during the night.



Allows you to enable additional programs when selected together with any wash cycle. After having selected the required wash cycle, press the button (



The Dry Assist + option, in addition to saving energy, ensures perfect drying of the dishes by opening the door automatically at the end of the washing cycle.



HYGIENE 99.9% High-temperature washing programme. The 75° rinse guarantees the removal of 99.9% of germs and bacteria.



The work aimed at continuous improvement has allowed the creation of the second generation of the Inverter motor 2.0, characterised by greater efficiency and durability over time, which allows very high performance and a lower energy consumption and noise level.



Benefit (TT)

Active Light

Maximum control thanks to the light projected on the floor that indicates when the dishwasher is running and when the cycle is complete

Smeg dishwashers equipped with ActiveLight signal the appliance's activity status by projecting a light on the floor while the cycle is running. The light goes out at the end of the cycle, signalling that the dishwasher can be unloaded.

FlexiDuo

The flexible third basket provides additional space, adapting to the load to accommodate various types of dishes, ensuring optimal organization and efficient use of interior capacity

The third FlexiDuo basket consists of two separate sections that can be handled independently of each other, stacked and/or removed, offering loading flexibility for every need. Depending on the arrangement, it allows cups, tall glasses, bulky utensils and pots and pans to be placed in the upper basket.

Planetarium Wash System

Full and deep wash coverage thanks to the advanced movement of the spray arm, an innovation patented by Smeg

Smeg's patented Planetarium Wash System guarantees impeccable cleaning. With a simultaneous double movement of the sprayer and 65 rotations per minute, it reaches every nook and cranny for extraordinary results. Dishes, glasses and utensils will be perfectly clean in no time. An intelligent system where efficiency and style meet, delivering brilliant results effortlessly.

Flexifit hinge system

Smooth-running door for optimal integration into the kitchen deisgn

The height of the plinth can vary from 5 cm to 21.5 cm, allowing it to fit perfectly into the cabinet. Thanks to this solution, the dishwasher blends harmoniously into its surroundings, with the door and plinth perfectly aligned with the other kitchen furniture.

DryAssist+

The Dry Assist+ system of automatic door opening at the end of the cycle ensures fast and energy-efficient drying