

# KITPLATE

Type

Chefplate

The dish baker is a Teflon-coated aluminum plate with the lower part of ferrous material immersed in a silicone rubber  
26,5 cm edges of the flare, 25 cm base

