

# LSP234CX



**Product Family** Dishwashers

Commercial width 60 cm Commercial height 82 cm

Installation Under counter built-in

N° baskets

EAN code 8017709305147



## **Programs**























N. of programmes 10 + 138, 45, 50, 55, 65, 70, 75 °C

Washing temperatures Soak Express 27' Yes Crystal Yes Full express - 60 Yes

minutes

**ECO** Yes Auto sensor 45-65

Yes Quiet (-2 dB) Yes Intense Yes Self clean Yes Hygiene 99,9% Yes

# **Options**









Dry Assist+ option **Delay timer option** 

Yes Up to 24 hours 1/2 load FlexiZone

Yes

Yes

option

Special programs option Yes

### **Baskets**





**Basket colour** 

**Basket components** colour

Handle

Grey

Grey

lower basket

In plastic on upper and

Largest loadable dish in 25,0 cm

upper basket

With 4 foldable racks Lower Basket

Lower basket with anti- Yes

drip inserts



**Upper Basket** 

Glass holder

Height adjustment of the upper basket

Sliding Guides Extra

Glide

With 3 foldable racks

Yes

On three levels (5 cm)

Yes

Largest loadable dish in 30,0 cm

lower basket

Colour Inner

Components **Cutlery basket** 

Yes

Blue

### **Technical Features**









Width (mm) Depth (mm) Display type

Product Height (mm)

Controls

Display

Programme graphics On/off indicator Salt light indicator Rinse aid indicator **Progress indicator** 

End of cycle indicator

Washing system Third spray arm Water softener **Turbidity sensor** 

Aquatest

598 mm 570 mm LED (external)

818 mm Flectronic

> Delayed start, Programme time indicator, Time to end

indication Symbols Yes

Light Light Yes

On display, with acoustic

signal Planetarium

Single With electronic setting

Yes

Flood protection system Total Acquastop

Water supply

Single; cold/hot water max. 60°C - energysave with hot

water up to 35%

Max water hardness

Drying system

100°fH;58°dH Natural condenser drying,

with Dry Assist + automatic door opening system at the

end of the cycle

100 - 170 mm

Steam protection In plastic Tub material Stainless steel Stainless steel Filter

Concealed heating

element

Self balancing with variable Hinges hinges

Yes

Min. and max plinth

height

Adjustable feet Additional gaskets 7 cm, from 820 to 890 mm Yes, with stainless steel

plate

Back cover Yes Depth of dishwasher 1146 with open door (mm)

Back feet adjustable

from front Top cover

Yes

In plastic

# Performance / Energy Label - Reg. 2019









**Energy Efficiency Class** C **73 KWh Energy consumption** [per 100 cycles, based

on the eco programme] Rated capacity (ps) 13 Water consumption [per 8,5 litres

cycle]

Programme duration Airborne acoustical noise emissions

Airborne acoustical noise emission class

**Energy efficiency Index** 

(EEI)

4:40 h:min 43 dB(A) re 1 pW

В

43.8

# **Electrical Connection**




Plug Connected power

Current Voltage (F;E) Schuko 1800 W 10 A 220-240 V

Frequency (Hz) Type of connection Power supply cable length

50 Hz Single-phase

140 cm





# **Compatible Accessories**

#### **KITGH**



Kit glass holder. It has to be fitted on the first basket but only if there are foldable



#### KITPL60N



Toekick Kit in Black colour with adjustable height and deepness. Can be installed over all the fully integrated and underbench models with variable fulcrum or flexifit hinges.




#### KITPL60X

KITPL60B

Toekick Kit in White colour with

be installed over all the fully integrated and underbench models with variable fulcrum or flexifit hinges.

adjustable height and deepness. Can



#### KITPLV2



Kit extension for dishwasher and washing machine: lenght mt. 2



## Symbols glossary



The Aquatest sensor is an electronic sensor that measures the degree of water transparency at the end of the initial soaking phase. ased on the values measured, the sensor sets the most suitable programme, thus obtaining the best washing results with the minimum amount of water.



To improve the drying of dishes without leaving stains.



82 cm high



Delay Timer: Option to postpone the start of the desired programme by up to 24 hours in order to programme the dishwasher to run at the desired time.



LED display: to show programmes, functions and options selected and the time to the end of the cycle.



FlexiZone: The ½ load flexizone allows you to wash a reduced load saving energy, water and time and there are no restrictions on where the items are placed.



The ExtraGlide guides system makes the second basket run even smoother and softer. It facilitates movement even when fully loaded, and thanks to the increased excursion, facilitates the insertion of dishes into the basket.



Noise Level: Excellent insulation and special devices keep noise to a minimum.



The Planetarium washing system, with high rotations per minute, guarantees complete coverage of the tank, thanks to the simultaneous rotation of base and sprayers, and excellent washing results.



Auto 45°- 65°: The auto programme regulates the length of a cycle depending on the need for a pre-wash and the number of rinses required.



Crystals: The Crystals programme is dedicated to delicate dishes such as glasses and china.



Eco: Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.



Mix: The Mix programme is suitable for mixed crockery and everyday pots and pans, without any particular incrustation.



Soak programme: The soak programme provides a rinse to prevent dirt from drying.



Express 27': The Express 27' programme is a quick wash cycle, at low temperatures, for lightly soiled dishes.



Ultraclean: The Ultraclean option performs a final rinse at a high temperature of 70°c eliminating virtually all bacteria.



 ${\bf 13\ place\ settings:}\ Number\ of\ place\ settings.$ 



Total Acquastop: In addition to the partial Acquastop protection present in all Smeg dishwashers, some models have an electronic device fitted to the water intake hose, which monitors water levels in the machine, detects leaks in the hose and switches off the water supply immediately when necessary.



System WaterSave ensures the best washing results with minimal water consumption depending on the model of dishwasher.



Quick wash cycle for normally soiled mixed loads such as dishes and pans, even with dried-on residues. Dishes are washed and dried in 60 minutes.





Dishwasher cleaning cycle. The cycle should be started with the machine empty, without dishes. It is recommended to run the program every 2-3 months, using special dishwasher detergents.



Allows you to enable additional programs when selected together with any wash cycle. After having selected the required wash cycle, press the button (



Energy efficiency class C



The work aimed at continuous improvement has allowed the creation of the second generation of the Inverter motor 2.0, characterised by greater efficiency and durability over time, which allows very high performance and a lower energy consumption and noise level.



SILENT: Wash cycle suitable for normally soiled dishes, even with dried-on residues. Ensures maximum noise reduction and is therefore ideal if you wish to run it during the night.



The Dry Assist + option, in addition to saving energy, ensures perfect drying of the dishes by opening the door automatically at the end of the washing cycle.



HYGIENE 99.9% High-temperature washing programme. The 75° rinse guarantees the removal of 99.9% of germs and bacteria.



## Benefit (TT)

#### Planetarium Wash System

Full and deep wash coverage thanks to the advanced movement of the spray arm, an innovation patented by Smeg

Smeg's patented Planetarium Wash System guarantees impeccable cleaning. With a simultaneous double movement of the sprayer and 65 rotations per minute, it reaches every nook and cranny for extraordinary results. Dishes, glasses and utensils will be perfectly clean in no time. An intelligent system where efficiency and style meet, delivering brilliant results effortlessly.

#### Extra Glide Telescopic Guides

Smoother and more stable loading and unloading operations

Extra Glide telescopic guides ensure smooth and safe extraction of the upper basket, even with heavy loads. The telescopic design ensures smooth, stable and silent movement, improving ergonomics and convenience. Ideal for optimising space and ease of use, they combine durability and comfort in every washing operation.

#### DryAssist+

The Dry Assist+ system of automatic door opening at the end of the cycle ensures fast and energy-efficient drying