

LSPU8643X



Product Family

Dishwashers

Commercial width

60 cm

Commercial height

86 cm

Installation

Under counter built-in

Nº baskets

3, FlexiDuo

EAN code

8017709303747



Programs



N. of programmes

10+1

Delicate

Yes

Washing temperatures

38, 45, 50, 55, 65, 70, 75 °F

Normal

Yes

Soak

Yes

Crystal & China

Yes

Express 27'

Yes

Eco express

Yes

Mix

Yes

Express 60'

Yes

Self clean

Yes

Pots & Pans

Yes

Sterilise

Yes

Options



Dry Assist option

Yes

1/2 load FlexiZone

Yes

Delay timer option

Up to 24 hours

option

Special programs option Yes

Baskets



Basket components colour

Grey

Lower Basket

With 2 foldable racks

Upper Basket

With 1 foldable rack

Lower basket with anti-

Yes

Glass holder

Yes

drip inserts

Height adjustment of the upper basket

On three levels (5 cm)

Largest loadable dish in lower basket

35,0 inches


| | | | |
|--|-------------|--------------------------------|------|
| Sliding Guides Extra Glide | Yes | Colour Inner Components | Blue |
| Largest loadable dish in upper basket | 18,0 inches | Cutlery basket | Yes |

Technical Features

| | | | |
|--|---|---|---|
|  |  |  | |
| Width (mm) | 23 9/16 " | Water softener | With electronic setting |
| Depth (mm) | 22 7/16 " | Flood protection system | Total Acquastop |
| Display type | LED (external) | Max water hardness | 100°fH;58°dH |
| Product Height (mm) | 32 3/16 " | Drying system | Natural condenser drying, with Dry Assist automatic door opening system at the end of the cycle |
| Display | Delayed start, Programme time indicator, Time to end indication | Tub material | Stainless steel |
| Programme graphics | Symbols | Filter | Stainless steel |
| On/off indicator | Yes | Concealed heating element | Yes |
| Salt light indicator | Light | Hinges | Self balancing with variable hinges |
| Rinse aid indicator | Light | Min. and max plinth height | 98 - 168 mm |
| Progress indicator | Yes | Adjustable feet | 7cm, from 860 to 930 mm |
| End of cycle indicator | On display, with acoustic signal | Additional gaskets | Yes |
| Auto switch-off | Yes | Back cover | Yes |
| Washing system | Orbital | Depth of dishwasher with open door (mm) | 1146 mm |
| Third spray arm | Single | Top cover | Metallic sheet |


Electrical Connection

| | | | |
|------------------------|-----------|----------------------------------|-------------------|
| Connected power | 1800 W | Type of connection | Single-phase |
| Current | 10 A | Power supply cable length | 140 " |
| Voltage | 110-120 V | Plug | (A) USA e Messico |
| Frequency (Hz) | 60 Hz | | |



Compatible Accessories

KITGH



Kit glass holder. It has to be fitted on the first basket but only if there are foldable racks

KITPL60N



Toekick Kit in Black colour with adjustable height and deepness. Can be installed over all the fully integrated and underbench models with variable fulcrum or flexifit hinges.

KITPLV2



Kit extension for dishwasher and washing machine: lenght mt. 2

KITPL60B



Toekick Kit in White colour with adjustable height and deepness. Can be installed over all the fully integrated and underbench models with variable fulcrum or flexifit hinges.



KITPL60X

Toekick Kit in Stainless Steel with adjustable height and deepness. Can be fitted over all the fully integrated and underbench models with variable fulcrum or flexifit hinges.

Symbols glossary

| | | | |
|--|--|---|--|
|  | To improve the drying of dishes without leaving stains. |  | 86 cm high |
|  | Delay Timer: Option to postpone the start of the desired programme by up to 24 hours in order to programme the dishwasher to run at the desired time. |  | LED display: to show programmes, functions and options selected and the time to the end of the cycle. |
|  | The Dry Assist option ensures optimal drying of the dishes by automatically opening the door at the end of the wash cycle. Reducing the rinse temperat |  | FlexiDuo: The FlexiDuo 3rd cutlery basket allows you to arrange cutlery or small cups, ladles, or bulky utensils however you like: it consists of two separate and moveable modules. |
|  | FlexiZone: The $\frac{1}{2}$ load flexizone allows you to wash a reduced load saving energy, water and time and there are no restrictions on where the items are placed. |  | The ExtraGlide guides system makes the second basket run even smoother and softer. It facilitates movement even when fully loaded, and thanks to the increased excursion, facilitates the insertion of dishes into the basket. |
|  | Noise Level: Excellent insulation and special devices keep noise to a minimum. |  | Orbital wash system distributes water evenly throughout the 60cm dishwasher cavity, directing water with precision to ensure an excellent wash. |
|  | Delicate: Delicate washing program is designed for delicate dishes which are not heavily soiled. |  | Mix: The Mix programme is suitable for mixed crockery and everyday pots and pans, without any particular incrustation. |
|  | Dishwasher cleaning cycle. The cycle should be started with the machine empty, without dishes. It is recommended to run the program every 2-3 months, using special dishwasher detergents. |  | Allows you to enable additional programs when selected together with any wash cycle. After having selected the required wash cycle, press the button (|
|  | Soak programme: The soak programme provides a rinse to prevent dirt from drying. |  | Express 27': The Express 27' programme is a quick wash cycle, at low temperatures, for lightly soiled dishes. |
|  | 13 place settings: Number of place settings. |  | Total Acquastop: In addition to the partial Acquastop protection present in all Smeg dishwashers, some models have an electronic device fitted to the water intake hose, which monitors water levels in the machine, detects leaks in the hose and switches off the water supply immediately when necessary. |
|  | STERYL 75°: Intensive wash cycle ideal for plates, pots, pans, cutting boards, feeding bottles. | | |