

# PL254CX





Product Family Dishwashers
Commercial width 60 cm
Commercial height 82 cm

**Installation** Partially-integrated built-in

2

Kitchen panel Not supplied

N° baskets

 Motor
 Inverter 2.0

 EAN code
 8017709307103



## **Programs**













Yes

Yes











N. of programmes 10 + 1Auto sensor 45-65 Yes Washing temperatures 38, 45, 50, 55, 65, 70, 75 °C Yes Soak Quiet (-2 dB) Yes Express 27' Yes Intense Yes Crystal Yes Self clean Yes Full express - 60 Hygiene 99,9% Yes Yes minutes

# **Options**



**ECO** 







Dry Assist+ option Delay timer option

<u>(S)</u>

Up to 24 hours

In plastic on upper and

lower basket

1/2 load FlexiZone

Yes

option

Special programs option Yes

## **Baskets**





Basket colour

Basket components colour

Handle

Grey Grey

Largest loadable dish in 25,0 cm

upper basket

**Lower Basket** With 2 foldable racks

Lower basket with anti- Yes

drip inserts



**Upper Basket** 

Glass holder

Height adjustment of the upper basket

Upper basket with EasyGlide System

With 1 foldable rack

Yes

On three levels (5 cm)

Yes

Largest loadable dish in 30,0 cm

lower basket

Colour Inner Components

**Cutlery basket** 

Blue

Yes

## **Technical Features**









Width (mm) Depth (mm) Display type

Product Height (mm) Controls

Display

Programme graphics On/off indicator Salt light indicator Rinse aid indicator **Progress indicator** 

End of cycle indicator

Washing system Third spray arm Water softener **Turbidity sensor** 

Aquatest

:::**/:::** 

598 mm 570 mm

LED (external) 818 mm Flectronic

> Delayed start, Programme time indicator, Time to end

indication Symbols Yes Light

Light Yes

On display, with acoustic

signal Orbital Single

With electronic setting

Yes

Flood protection system Total Acquastop

Water supply

Single; cold/hot water max. 60°C - energysave with hot

water up to 35% 100°fH;58°dH

Max water hardness

Drying system

door opening system at the end of the cycle Steam protection In plastic

Tub material Stainless steel Stainless steel Filter Yes

Concealed heating element

Hinges

Min. and max plinth

height

Adjustable feet

Back cover

hinges 100 - 215 mm

Self balancing with variable

Natural condenser drying,

with Dry Assist + automatic

7 cm, from 820 to 890 mm

Yes, with covered counterweight 1146 mm

Depth of dishwasher with open door (mm) Back feet adjustable

from front

Yes

Top cover In plastic

# Performance / Energy Label - Reg. 2019

13









**Energy Efficiency Class** C

73 kWh **Energy consumption** [per 100 cycles, based on the eco programme]

Rated capacity (ps) Water consumption [per 8,5 litres

cycle]

Programme duration Airborne acoustical

noise emissions Airborne acoustical noise emission class

**Energy efficiency Index** 

4:40 h:min

45 dB(A) re 1 pW

С

43,8

(EEI)


# **Electrical Connection**



Connected power 1800 W
Current 10 A
Voltage 220-240 V
Frequency (Hz) 50 Hz

Type of connection Power supply cable length Plug Single-phase 140 cm

(F;E) Schuko





# **Compatible Accessories**

### **KITGH**



Kit glass holder. It has to be fitted on the first basket but only if there are foldable

#### KITPL60N




Toekick Kit in Black colour with adjustable height and deepness. Can be installed over all the fully integrated and underbench models with variable fulcrum or flexifit hinges.



#### KITPL60X

KITPL60B



Toekick Kit in White colour with

be installed over all the fully integrated and underbench models with variable fulcrum or flexifit hinges.

adjustable height and deepness. Can

#### KITPLV2



Kit extension for dishwasher and washing machine: lenght mt. 2



## Symbols glossary



The Aquatest sensor is an electronic sensor that measures the degree of water transparency at the end of the initial soaking phase. ased on the values measured, the sensor sets the most suitable programme, thus obtaining the best washing results with the minimum amount of water.



To improve the drying of dishes without leaving stains.



82 cm high



Delay Timer: Option to postpone the start of the desired programme by up to 24 hours in order to programme the dishwasher to run at the desired time.



LED display: to show programmes, functions and options selected and the time to the end of the cycle.



EasyGlide: Convenient EasyGlide system for easy unloading of the appliance that allows reaching maximum flexibility of load of the machine.



FlexiZone: The ½ load flexizone allows you to wash a reduced load saving energy, water and time and there are no restrictions on where the items are placed.



Noise Level: Excellent insulation and special devices keep noise to a minimum.



Orbital wash system distributes water evenly throughout the 60cm dishwasher cavity, directing water with precision to ensure an excellent wash.



Auto 45°- 65°: The auto programme regulates the length of a cycle depending on the need for a pre-wash and the number of rinses required.



Crystals: The Crystals programme is dedicated to delicate dishes such as glasses and china.



Eco: Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.



Mix: The Mix programme is suitable for mixed crockery and everyday pots and pans, without any particular incrustation.



Soak programme: The soak programme provides a rinse to prevent dirt from drying.



Express 27': The Express 27' programme is a quick wash cycle, at low temperatures, for lightly soiled dishes.



Ultraclean: The Ultraclean option performs a final rinse at a high temperature of 70°c eliminating virtually all bacteria.



13 place settings: Number of place settings.



Total Acquastop: In addition to the partial Acquastop protection present in all Smeg dishwashers, some models have an electronic device fitted to the water intake hose, which monitors water levels in the machine, detects leaks in the hose and switches off the water supply immediately when necessary.



System WaterSave ensures the best washing results with minimal water consumption depending on the model of dishwasher.



Quick wash cycle for normally soiled mixed loads such as dishes and pans, even with dried-on residues. Dishes are washed and dried in 60 minutes.





Dishwasher cleaning cycle. The cycle should be started with the machine empty, without dishes. It is recommended to run the program every 2-3 months, using special dishwasher detergents.



Allows you to enable additional programs when selected together with any wash cycle. After having selected the required wash cycle, press the button (



Energy efficiency class C



**8,7** 

The work aimed at continuous improvement has allowed the creation of the second generation of the Inverter motor 2.0, characterised by greater efficiency and durability over time, which allows very high performance and a lower energy consumption and noise level.



SILENT: Wash cycle suitable for normally soiled dishes, even with dried-on residues. Ensures maximum noise reduction and is therefore ideal if you wish to run it during the night.



The Dry Assist + option, in addition to saving energy, ensures perfect drying of the dishes by opening the door automatically at the end of the washing cycle.



HYGIENE 99.9% High-temperature washing programme. The 75° rinse guarantees the removal of 99.9% of germs and bacteria.

