

SE2321TE2



Product Family
Built-in type
Dimensions
Power supply
Type
EAN code

Hob
Traditional
30 cm
Electric
Ceramic
8017709138622



Aesthetics



Aesthetic

Universale

Colour

Black

Finishing

Glass

Material

Glass

Glass type

Ceramic

Glass edge

Angled edge

Type of control setting

Digi Touch

Control knob position

Front

Logo

Silk screen

Serigraphy colour

White

Program / Functions



No. of ceramic cook zones

2

No. of cooking zones with booster

2

Power levels

9

Total no. of cook zones

2

Options



Control Lock / Child
Safety

Yes

Technical Features



Front-centre - Ceramic - Single - 1.20 kW - Ø 14.0 cm

Rear-centre - Ceramic - Double - 0.80 - 2.00 kW - Ø 11.0 - Ø 17.5 cm

Automatic switch off
when overheat

Yes

Residual heat indicator

Yes

Automatic switch off
when overflow

Yes

Electrical Connection

Electrical connection
rating (W)


3200 W

Frequency (Hz)
Plug

50/60 Hz
Not present

Voltage (V)

220-240 V











Compatible Accessories



SCRP

Non-scratch hob scraper - suitable for induction and ceramic hobs

Symbols glossary

	Power booster: option allows the zone to work at full power when very intense cooking is necessary.		Standard installation: Traditional installation in tabletop, suitable for any kitchen sets.
	Child lock: some models are fitted with a device to lock the programme/cycle so it cannot be accidentally changed.		Overheat protection: The safety system that automatically turns off the hob in case of overheating of the control unit.
	Glass ceramic: The base of the hob is made glass ceramic. Heating is performed by the heating elements Hi-Light.		Overfill protection: The special overfill protection shuts down the stove in the presence of overflow of liquids.
	Indication of residual heat: After the glass ceramic hob is switched off the residual heat indicator shows which of the heating zones still remains hot. When the temperature drops below 60 ° C, the indicator goes out.		Touch control