

## SI2321D



### Product Family

Built-in

Dimensions

Power supply

Type

EAN code

Hob


Ultra-low profile or Fully Flushed

30 cm

Electric

Induction

8017709330644



## Aesthetics



### Aesthetics

Colour

Finishing

Material

Glass Type

Glass edge

Type of control setting

Slider

Control knobs position

Logo

Serigraphy colour

Universal

Black

Glass

Glass

Ceramic

Straight edge

Digi Touch

Red

Front

Silk screen

Grey

## Program / Functions



No. of induction cook zones

2

No. of cooking zones with booster

2

Main on/off switch

Yes

Power levels

9

Total no. of cook zones

2

## Options



<b>Standard cut out</b>	478-482x252-256 mm	<b>Residual time indicator</b>	Yes
<b>End cooking timer</b>	2	<b>Control Lock / Child</b>	Yes
<b>Minute minder</b>	1	<b>Safety</b>	
<b>End of cooking acoustic alarm</b>	Yes	<b>Quick start</b>	Yes

## Technical Features




Front centre - Induction - single - 1.20 kW - Booster 1.60 kW - Ø 14.5 cm

Rear centre - Induction - single - 1.50 kW - Booster 2.00 kW - Ø 21.0 cm

<b>Automatic setting according to pan dimension</b>	Yes	<b>Residual heat indicator</b>	Yes
<b>Automatic pan detection</b>	Yes	<b>Eco-Off</b>	Yes
<b>Minimum pan diameter indication</b>	Yes	<b>Protection against accidental start up</b>	Yes
<b>Automatic switch off when overheat</b>	Yes		

## Electrical Connection

<b>Nominal power (W)</b>	3600 W	<b>Frequency (Hz)</b>	50/60 Hz
<b>Current</b>	16 A	<b>Power supply cable length</b>	120 cm
<b>Voltage (V)</b>	220-240 V	<b>Plug</b>	No
<b>Type of electric cable</b>	Single phase		



---

## Compatible Accessories

---



**SCRP**

Induction and ceramic hobs and teppanyaki scraper

## Symbols glossary



Power booster: option allows the zone to work at full power when very intense cooking is necessary.



Touch control



Overheat protection: The safety system that automatically turns off the hob in case of overheating of the control unit.



Quick Start function: the chosen temperature is reached faster. The heating element works at maximum power until the right temperature is reached.



Time elapsed: shows how long the cooking zone has been in use.



Child lock: some models are fitted with a device to lock the programme/cycle so it cannot be accidentally changed.



Eco-Off: This energy-saving function shuts the zone down before the timer sounds, making use of the residual heat in the pan.



Induction: The work of these hobs is based on the principle of electromagnetic induction. The heat is generated directly in the bottom of the pan during its contact with the hob.



Indication of residual heat: After the glass ceramic hob is switched off the residual heat indicator shows which of the heating zones still remains hot. When the temperature drops below 60 °C, the indicator goes out.



Timer: All ceramic hobs have a timer which automatically ends cooking after a preset time.