

# SI2321D




**Product Family** 

Built-in Ultra-low profile or Fully Flushed

Hob

Dimensions30 cmPower supplyElectricTypeInduction

EAN code 8017709330644



#### **Aesthetics**



**Aesthetics** Universal Colour Black Glass **Finishing** Material Glass Glass Type Ceramic Glass edge Straight edge Type of control setting Digi Touch Slider Red Control knobs position Front Silk screen Logo Serigraphy colour Grey

### **Program / Functions**



No. of induction cook zones 2
No. of cooking zones with booster 2
Main on/off switch Yes
Power levels 9
Total no. of cook zones 2

### **Options**













Standard cut out 478-482x252-256 mm Residual time indicator Yes End cooking timer 2 Control Lock / Child Yes

Minute minder 1 Safety
End of cooking acoustic Yes Quick start Yes

alarm

#### **Technical Features**



Front centre - Induction - single - 1.20 kW - Booster 1.60 kW - Ø 14.5 cm Rear centre - Induction - single - 1.50 kW - Booster 2.00 kW - Ø 21.0 cm

Automatic setting Yes Residual heat indicator Yes according to pan Eco-Off Yes dimension Protection against Yes

Automatic pan Yes accidental start up detection


Minimum pan diameter Yes

indication

Automatic switch off Yes when overheat

#### **Electrical Connection**

Nominal power (W) 3600 W Type of electric cable Single phase Current 16 A Frequency (Hz) 50/60 Hz Voltage (V) 220-240 V Power supply cable length 120 cm





# **Compatible Accessories**



#### **SCRP**

Induction and ceramic hobs and teppanyaki scraper



#### **TPK**

Stainless steel grill plate to cook Teppanyaki dishes



### Symbols glossary



Power booster: option allows the zone to work at full power when very intense cooking is necessary.



Child lock: some models are fitted with a device to lock the programme/cycle so it cannot be accidentally changed.



Touch control



Eco-Off: This energy-saving function shuts the zone down before the timer sounds, making use of the residual heat in the pan.



Overheat protection: The safety system that automatically turns off the hob in case of overheating of the control unit.



Induction: The work of these hobs is based on the principle of electromagnetic induction. The heat is generated directly in the bottom of the pan during its contact with the hob.



Quick Start function: the chosen temperature is reached faster. The heating element works at maximum power until the right temperature is reached.



Indication of residual heat: After the glass ceramic hob is switched off the residual heat indicator shows which of the heating zones still remains hot. When the temperature drops below 60 ° C, the indicator goes out.



Time elapsed: shows how long the cooking zone has been in use.



Timer: All ceramic hobs have a timer which automatically ends cooking after a preset time.