

SIM6964R



Product Family
Built-in
Dimensions
Power supply
Type
EAN code

Hob
Traditional
90 cm
Electric
Induction
8017709309770



Aesthetics



Aesthetics
Colour
Finishing
Material
Glass Type
Glass edge
Type of control setting
Slider
Slider
Control knobs position
Logo
Serigraphy colour

Dolce Stil Novo
Black
Copper
Glass
Eclipse ceramic
Straight edge
Multi Slider
Yes
White
Front
Silk screen
Grey

Program / Functions



No. of induction cook zones
Time-setting options
No. of cooking zones with booster
No. of Flexible zones
Main on/off switch
Power levels
Auto-Vent 2.0
Total no. of cook zones

6
Automatic switch-off
6
3
Yes
9
Yes
6

Options



| | | | |
|-------------------------------------|------------|--|---------------------------|
| Multizone Option | Yes | End of cooking acoustic alarm | Yes |
| Flexible Zone Type | MultiZone | Residual time indicator | Yes |
| Standard cut out | 490x880 mm | Limited Power Consumption Mode | Yes advance |
| Double Booster | Yes | Limited Power Consumption Mode in W | 1400 a 11100 - step 100 W |
| Keep warm automatic function | Yes | Show Room Demo Option | Yes |
| Grill function | Yes | Control Lock / Child Safety | Yes |
| End cooking timer | 6 | Bridge option | Yes auto |
| Pause option | Yes | Quick start | Yes |
| Minute minder | 1 | Rapid level selection | Yes |

Technical Features




| | |
|---|--|
| Front left - Induction - Multizone - 2.10 kW - Booster 2.50 kW - Double booster 3 kW - 24.0x18.0 cm | |
| Rear left - Induction - multizone - 2.10 kW - Booster 2.50 kW - Double booster 3 kW - 24.0x18.0 cm | |
| Front centre - Induction - Multizone - 2.10 kW - Booster 2.50 kW - Double booster 3 kW - 24.0x18.0 cm | |
| Rear centre - Induction - multizone - 2.10 kW - Booster 2.50 kW - Double booster 3 kW - 24.0x18.0 cm | |
| Front right - Induction - Multizone - 2.10 kW - Booster 2.50 kW - Double booster 3 kW - 24.0x18.0 cm | |
| Rear right - Induction - multizone - 2.10 kW - Booster 2.50 kW - Double booster 3 kW - 24.0x18.0 cm | |
| Multizone left - Booster 3.7 kW - 38.5x23.0 cm | |
| Multizone center - Booster 3.7 kW - 38.5x23.0 cm | |
| Multizone right - Booster 3.7 kW - 38.5x23.0 cm | |

| | | | |
|--|---------------|---|-----|
| Automatic setting according to pan dimension | Yes | Automatic switch off when overflow | Yes |
| Automatic pan detection | Yes, min 9 cm | Residual heat indicator | Yes |
| Permanent Automatic Pot Detection with indication of the relative control | Yes | Protection against accidental start up | Yes |
| Automatic switch off when overheat | Yes | | |

Electrical Connection

| | | | |
|-------------------------------|-------------|--|------------------------------|
| Nominal power (W) | 11100 W | Type of electric cable supplied | Yes, Single and Double phase |
| Current | 49 A | Frequency (Hz) | 50/60 Hz |
| Voltage (V) | 220-240 V | | |
| Voltage 2 (V) | 380-415 V | | |
| Type of electric cable | Three-phase | | |

| | | | |
|------------------------|-------------------------|---------------------------|---------|
| Type of electric cable | Single and Double phase | Power supply cable length | 120 cm |
| | | Terminal Box | 5 poles |
| | | Plug | No |



Compatible Accessories



GRILLPLATE

Universal griddle for induction, gas, ceramic and electric hobs. Non-stick surface ideal for cooking meat, cheese and vegetables. Dimensions: 410 x 240 mm.



TPKPLATE
























Universal plate for induction, gas, ceramic and electric hobs. Non-stick surface ideal for cooking fish, eggs and vegetables. Dimensions: 410 X 240 mm.



SCRP

Induction and ceramic hobs and teppanyaki scraper

Symbols glossary

| | | | |
|--|--|---|--|
|  | Permanent auto pot detection |  | Connection between hob and hood |
|  | Power booster: option allows the zone to work at full power when very intense cooking is necessary. |  | Standard installation: Traditional installation in tabletop, suitable for any kitchen sets |
|  | Child lock: some models are fitted with a device to lock the programme/cycle so it cannot be accidentally changed. |  | Premium individual Slider control for each zone |
|  | The slider control panel allows you to adjust the power simply by passing your finger across the touch device. |  | Additional maximum power level for a better energy consumption |
|  | Darkness becomes light |  | Grill function |
|  | Keep warm function: Keep warm function keeps the cooked food heated. In this mode the heating zone operates at a minimum capacity for 120 minutes and then turns off automatically. |  | Overheat protection: The safety system that automatically turns off the hob in case of overheating of the control unit. |
|  | Induction: The work of these hobs is based on the principle of electromagnetic induction. The heat is generated directly in the bottom of the pan during its contact with the hob. |  | Multizone: allows several pans to be used at once, large or small, offering freedom of placement and greater flexibility |
|  | Overfill protection: The special overfill protection shuts down the stove in the presence of overflow of liquids. |  | Min diameter pot detection of 9 cm |
|  | PAUSE_72dpi |  | Possibility to set the maximum power absorption of the hob |
|  | Quick selection, with one touch cooking begins at the highest level, then automatically reduces after time. Ideal for dishes that require quick boiling and then continued cooking without constant control (eg beef broth). |  | Quick Start function: the chosen temperature is reached faster. The heating element works at maximum power until the right temperature is reached. |
|  | Indication of residual heat: After the glass ceramic hob is switched off the residual heat indicator shows which of the heating zones still remains hot. When the temperature drops below 60 ° C, the indicator goes out. |  | Time elapsed: shows how long the cooking zone has been in use. |
|  | Timer: All ceramic hobs have a timer which automatically ends cooking after a preset time. | | |