

SPG403M

Family	Professional dishwasher
Subfamily	Undercounter glasswashers
Line	Ecoline
Basket dimensions	400x400 mm
Wash pump	Standard



Accessories Included

Cutlery basket	1x PHOOS01	Water supply hose	Yes - 1,5m
Flat basket	2x PB40G01	Drain hose	Yes - 2m

Target

Solutions	Coffee shops/Wine bars
-----------	------------------------

Programs

Programs	3 automatic programs; Self-cleaning programs
Program options	Extra rinse; Clean water cycle
Program table	Electronic Ecoline glasswasher 400
Program specifications	Boiler 83°C / Tank 60°C - 4'; Boiler 83°C / Tank 60°C - 1' 30"; Boiler 83°C / Tank 60°C - 2' 30"
Maximum basket/hour	40
Maximum dishes/hour	320
Maximum glasses/hour	1000

Interface

Display	4 digit	On/Off button	Yes
Number of buttons	5	Manual diagnostic	Yes

Construction

Tank	Deep drawn	Rack guides	Embossed
Construction	Partial double-skin	Filter	4-stage filter system
Tank material	Stainless steel AISI 304	Tank capacity	7 l
Back panel	Galvanized	Boiler capacity	4,5 l
Upper wash system	One wash and one split rinse spray arms, stainless steel	Protection class	IPX4
Lower wash system	One wash and one combined rinse spray arms, stainless steel and plastic	Adjustable feet	Yes
Tank filter	Plastic	Drain max. height	600 mm
Door gasket	Only up		

Technical Features


Tank heating element power	1400 W	Max water hardness	12°f - 7°dH
Boiler heating element power	2700 W	Inlet pressure	250-1000 kPa (min-max)
Wash pump power	290 W	Detergent load	1,5 l/h
Default connection	3100 W	Rinse load	0,4 l/h
Water consumption per cycle	3 l	Usable load height	309 mm
Minimum water consumption per cycle	3 l	Depth with open door	882 mm
Warm water connection	5°C	Product dimensions WxDxH	440x555x695 mm
Max. inlet temperature	60°C		

Electrical Connection

Plug	(F;E) Schuko	Power connection	230 V~ / 14 A / 3,1 kW / 50 Hz
-------------	--------------	-------------------------	--------------------------------

Equipments

Drain pump	Yes	Option for auto daily switch on	Yes, default OFF
Peristaltic detergent dispenser	Electronic control	Cycle counter	Yes
Peristaltic rinse-aid dispenser	Electronic control	Partial renewal of water in the tank and built-in drain pump	Yes
Default chemicals dosing unit of measure	gr/lt	Water supply pipe diameter	DN15 - ½"
Rinse boiler Thermostop system	Yes - default	Drain supply pipe diameter	DN20-G 3/4"
Wash tank Thermostop system	Yes	Detergent (red) hose lenght	2,2m
Wash pump soft start system	Yes	Rinse aid (blue) hose lenght	2,2m




R	Pannello retro	Lower back panel
Q	Morsetto equipotenziale	Earth terminal
C	Tubo di carico	Filler hose
S	Tubo di scarico	Drain hose
P	Tubi pompe peristaltiche	Peristaltic hoses
E	Cavo alimentazione elettrica	Electricity supply cable

Compatible Accessories



KITRB40G01

Kit of 2 wire round baskets and adaptor for Ecoline



PB40G01

Universal flat bottom polypropylene basket, dim. (WxDxH) 400x400x125 mm



PHOOS01

Polypropylene single basket for cutlery



RB40A3

Adapter for round basket for all glasswasher models 460 mm wide



WB40D01

Wire basket for 8 dishes Ø315 mm, dim. 400x400 mm



WB40G02

Wire basket with sloped bottom for glasses Ø90 mm max, dim. (WxDxH) 400x400x168 mm



WB40PG4

Wire basket for plastic glasses, dim. (WxDxH) 400x400x210 mm



PB40C02

Universal flat bottom polypropylene double basket, dim. (WxDxH) 400x400x227 mm



PHOGR4

Glass insert for 400x400 mm basket




PHOOS02

6 compartment polypropylene basket for cutlery



RB40G01

Universal wire basket with flat bottom, dim. (ØxH) 400x140 mm



WB40G01

Universal wire basket with flat bottom, dim (WxDxH) 400x400x120 mm



WB40G03

Sloped bottom 3 compartments wire basket for glasses Ø120 mm max, dim. (WxDxH) 400x400x168 mm



WH00S01

Wire insert for 12 small dishes



WS4

Stainless steel underframe for glasswashers, dim. (WxDxH) 495x530x490 mm

Symbols glossary



4 STAND FILTER



MAX.USABLE HEIGHT 309mm

Benefit (TT)

Interface

Control panel with electronic buttons

The electronic control panel features an intuitive interface with soft-touch buttons, allowing easy selection of one of the three wash programmes: short, medium, or intensive. There are also buttons for power, selection, and cycle start. The display provides real-time monitoring of the tank and boiler temperature, as well as diagnostics, ensuring effortless and immediate control of the main functions.

4-stage filtration system

Deep cleaning and spotless washes with the Patented 4-Stages Filtration System

The innovative Smeg filtration system consists of 4 stages to completely eliminate all impurities: the 1st stage captures larger food residues; in the 2nd stages, finer particles are captured at this filtration stage; the 3th stage features a pre-filtration grid to prevent debris from entering the tank and clouding the water. Finally, the last stage is designed to further protect the washing and draining pumps from any debris that may accidentally enter the tank during filter cleaning.

Moulded tank

Superior washing performance and enhanced cleaning convenience with molded tub bottoms and basket guides

Smeg dishwashers are designed with moulded tank and basket guides. The absence of sharp edges ensures an optimised wash flow, guaranteeing hygiene and impeccable cleaning performance. Furthermore, this innovative design simplifies machine cleaning, reducing the need for maintenance interventions.

Partial double-skin

Optimised thermal and acoustic insulation

The Ecoline undercounter dishwashers are equipped with a partial double-skin structure that optimises energy efficiency by minimising heat loss. Additionally, it provides effective acoustic insulation, helping to reduce noise levels and ensuring a quieter, more comfortable working environment for staff.

Drain pump

Partial water replacement during the wash cycle for clean and hygienic dishes

The standard drain pump, equipped with a partial water exchange system, ensures that the dirtiest water is automatically removed at every wash cycle. This mechanism allows for continuous renewal of the water used, ensuring that each phase of the washing process is carried out with clean water. The result is optimal dishwashing performance, with outstanding efficiency and an impeccable level of hygiene.

Soft-start system

Effective management of the washing pump to protect your glassware

The Soft-Start function initiates the wash cycle gently and gradually, progressively increasing the water pressure. This system has been designed to provide optimal protection for the most fragile items, such as crystal glasses, significantly reducing the risk of chipping or damage. At the same time, it ensures excellent cleaning performance, combining efficiency and safety in every wash cycle.