

SPG403ML

Family Subfamily

Line

Basket dimensions Wash pump

Power connection

Professional dishwasher Undercounter glasswashers

Ecoline 400x400 mm

Standard

230 V~ / 14 A / 3,1 kW /50 Hz



Accessories included

Cutlery basket Flat basket 1x PHOOS01 2x PB40G01 Water supply hose Drain hose Yes - 1,5m Yes - 2m

Target

Solutions

Coffee shops/Wine bars

Programs

Programs

Program options

Program table

Maximum basket/hour Maximum dishes/hour Maximum glasses/hour 3 automatic programs; Self-cleaning programs

Extra rinse; Clean water cycle

Electronic Ecoline glasswasher 400

40 320 1000

Interface

Display

4 digit

Number of buttons 5

On/Off button
Manual diagnostic

Yes Yes

Construction

Tank

Deep drawn

Rack guides

Embossed



Construction Partial double-skin

Tank material Stainless steel AISI 304

Back panel Galvanized

Upper wash system One wash and one split

rinse spray arms, stainless

steel

Lower wash system One wash and one

combined rinse spray arms, stainless steel and plastic

Tank filter **Plastic** Door gasket Only up Filter 4-stage filter system

Tank capacity 8 I **Boiler** capacity 4,5 I **Protection class** IPX4 Adjustable feet Yes Drain max. height 600 mm

Technical Features

Water consumption per

cycle

60°C Wash temperature

(min-max)

Rinse temperature (min- 83 °C

max)

Minimum water 3 I

consumption per cycle

Min. water connection

temperature

60°C Max. inlet temperature

Max water hardness 12°f - 7°dH Inlet pressure

Detergent load Rinse load Usable load height

Depth with open door **Product dimensions**

WxDxH

250-1000 kPa (min-max)

1.5 l/h 0,4 l/h 309 mm 882 mm

440x555x670 mm

Electrical Connection

Plug (F;E) Schuko

Tank heating element power

Boiler heating element

power

1400 W

2800 W

5°C

Wash pump power **Default connection**

Optional electrical

connection

290 W

3100 W

220 V~ / 14 A / 3,1 kW / 50

Ηъ

Equipments

Drain pump Yes Option for auto daily

Peristaltic detergent

Peristaltic rinse-aid

dispenser

Electronic control Electronic control

dispenser

Deafult chemicals

dosing unit of measure

Rinse boiler Thermostop Yes - default

system

system

Wash tank Thermostop

gr/lt

Yes

Wash pump soft start Yes

system

switch on

Cycle counter Partial renewal of water Yes in the tank and built-in

drain pump

Water supply pipe

diameter

Drain supply pipe diameter

Detergent (red) hose

lenght

Rinse aid (blue) hose

lenght

Yes, default OFF

Yes


DN15 - 1/2"

DN20-G 3/4"

2,2m

2,2m







Compatible Accessories

KITRB40G01

Kit of 2 wire round baskets and adaptor for Ecoline



PB40C02

Universal flat bottom polypropylene double basket, dim. (WxDxH) 400x400x227 mm



PB40G01

Universal flat bottom polypropylene basket, dim. (WxDxH) 400x400x125 mm



PHOOGR4

Glass insert for 400x400 mm basket



PHOOS01

Polypropylene single basket for cutlery



PHOOS02

6 compartment polypropylene basket for cutlery



RB40A3

Adapter for round basket for all 400 glasswasher models 460 mm wide



RB40G01

Universal wire basket with flat bottom, dim. (ØxH) 400x140 mm



WB40D01

Wire basket for 8 dishes Ø315 mm, dim.400x400 mm



WB40G01

Universal wire basket with flat bottom, dim (WxDxH) 400x400x120 mm



WB40G02

Wire basket with sloped bottom for glasses Ø90 mm max, dim. (WxDxH) 400x400x168 mm



WB40G03

Sloped bottom 3 compartments wire basket for glasses Ø120 mm max, dim. (WxDxH) 400x400x168 mm



WB40PG4

Wire basket for plastic glasses, dim. (WxDxH) 400X400X210 mm



WH00S01

Wire insert for 12 small dishes



WS4

Stainless steel underframe for glasswashers, dim. (WxDxH) 495x530x490 mm



Symbols glossary



4 STAND FILTER



MAX.USABLE HEIGHT 309mm



Benefit (TT)

Interface

Control panel with electronic buttons

The electronic control panel features an intuitive interface with soft-touch buttons, allowing easy selection of one of the three wash programmes: short, medium, or intensive. There are also buttons for power, selection, and cycle start. The display provides real-time monitoring of the tank and boiler temperature, as well as diagnostics, ensuring effortless and immediate control of the main functions.

4-stage filtration system

Deep cleaning and spotless washes with the Patented 4-Stages Filtration System

The innovative Smeg filtration system consists of 4 stages to completely eliminate all impurities: the 1st stage captures larger food residues; in the 2nd stages, finer particles are captured at this filtration stage; the 3th stage features a pre-filtration grid to prevent debris from entering the tank and clouding the water. Finally, the last stage is designed to further protect the washing and draining pumps from any debris that may accidentally enter the tank during filter cleaning.

Moulded tank

Superior washing performance and enhanced cleaning convenience with molded tub bottoms and basket guides

Smeg dishwashers are designed with moulded tank and basket guides. The absence of sharp edges ensures an optimised wash flow, guaranteeing hygiene and impeccable cleaning performance. Furthermore, this innovative design simplifies machine cleaning, reducing the need for maintenance interventions.

Partial double-skin

Optimised thermal and acoustic insulation

The Ecoline undercounter dishwashers are equipped with a partial double-skin structure that optimises energy efficiency by minimising heat loss. Additionally, it provides effective acoustic insulation, helping to reduce noise levels and ensuring a quieter, more comfortable working environment for staff.

Drain pump

Partial water replacement during the wash cycle for clean and hygienic dishes

The standard drain pump, equipped with a partial water exchange system, ensures that the dirtiest water is automatically removed at every wash cycle. This mechanism allows for continuous renewal of the water used, ensuring that each phase of the washing process is carried out with clean water. The result is optimal dishwashing performance, with outstanding efficiency and an impeccable level of hygiene.

Soft-start system

Effective management of the washing pump to protect your glassware

The Soft-Start function initiates the wash cycle gently and gradually, progressively increasing the water pressure. This system has been designed to provide optimal protection for the most fragile items, such as crystal glasses, significantly reducing the risk of chipping or damage. At the same time, it ensures excellent cleaning performance, combining efficiency and safety in every wash cycle.